



EZ Node™ Wireless Node - Model Number Matrix

More time at the Face.

Series = EZ Node™ Wireless Adapter

1 = Options



EZN = EZ Node™ Wireless Adapter

The EZ Node™ Wireless Adapter allows any Maestro product to connect directly to a wireless network.

Enclosure Specifications:
NEMA 4X enclosure;
ABS construction;
Heavy duty aluminum back plate with stainless steel hardware.

E = Ethernet, IEEE 802.11b/g compliant, 2.4 GHz Wireless radio, PoE (Power over Ethernet), 1 X 10/100 BASE-TX (Cat. 5, RJ-45) Ethernet Interface, FCC Part 15.247, IC RS210 & CE Wireless approvals, RoHS Compliance c/w 3 dBi Omni-directional antenna, waterproof RJ45 connector and one 24 VDC power injector to be installed in any Ethernet based Maestro product, discovery tool, The EZ Node™ is configured through a simple web browser and requires no additional software.

LFV = Leaky Feeder, VHF Radio modem, 148 – 174 MHz, c/w unity gain stub VHF antenna, (Customer to provide upstream and downstream frequencies with order).

LFU = Leaky Feeder, UHF Radio modem, 450 – 480 MHz, c/w unity gain stub UHF antenna, (Customer to provide upstream and downstream frequencies with order).

NOTE 1: Leaky Feeder applications will require the Vigilante AQS™, AirScout™, GasMon™, EthernetI/O™ or SuperBrite™ Marquee Display to be configured with RS485 as the physical layer.

NOTE 2: Leaky Feeder applications will require a EZ Base™ Leaky Feeder Head End chassis and Protocol Converters..

Series



EZN

Options



1

Increase Safety and Productivity